

SANITARY

Product for preventive disinfection of supports to be waterproofed with PVC-P coating. TEXPOOL SANITARY can be used in new masonry and concrete structures, but should always be used to remodel existing PVC-P-lined pools. TEXPOOL SANITARY is a Preventol (Bayer)-based product

MANUFACTURING STANDARDS

250 ml bottle
2.5% solution

INSTALLATION

The product should be stored, appropriately sealed, in a cool, dry place.

- Remove the existing PVC sheet;
- Air out the structure for 1 day;
- Clean the structure repeatedly with sodium hypochlorite (until it is fully cleaned);
- Let the structure dry;
- Dilute 250 ml of Texpool Sanitary in 10 liters of water (2.5% solution);
- Mix well before use;
- With the appropriate roller, smooth the product uniformly (do not spray);
- Let the structure dry;
- Repeat the "disinfecting" steps;
- Let the structure dry;
- Install the new PVC;
- The solution can treat a surface approximately 35 m² (depending on the dryness and porosity of said surface).

Note: disinfection of the structure can be ineffective if water has infiltrated the structure and/or in case of rain.

Synthetic Waterproofing Texpool

TEXSA SYSTEMS SLU reserves the right to modify the information contained herein without prior notice and declines all liability in cases of errors produced due to inappropriate use of the product. The values shown in the technical sheet are the mean values from tests in our lab.